



1. Measure the height and width of the area you'll be covering with AMS Wood Panels.
2. Install furring strips every 24" on center. The framework created should run perpendicular to the length of AMS Wood Panels.
3. If required, cut panels to size.
 - Use a circular saw to cut the panels to height.

TIP: Applying masking tape on the wood surface prior to cutting can help prevent splintering or splitting.

 - Use a utility knife or equivalent to cut the panels to width by cutting through the black PET backing.
4. After cuts are made, reattach the AMS Wood Panels to the black PET backing with screws or staples of appropriate length working from the backside of the panel.
5. Installation can commence. Position and secure AMS Wood Panels to the furring strips with screws placed 12" on center horizontally and 24" on center vertically at the furring strip locations. **NOTE:** Screws should be applied through the black PET felt and NOT the panels. Doing so could cause spitting or splintering of the product.

TIP: Maintain even spacing and avoid visible seams using the built-in shiplap.
6. Repeat the process until you achieve desired coverage.

TIP: If required, cut edges may be concealed with finish trim or decorative molding supplied by others.

NOTE: Furring strips can be omitted if the wall surface is capable of supporting a direct screw attachment.

Assess your space and follow the installation instructions most appropriate for your circumstances and skill level.