



ACOUSTICAL WALL PANEL INSTALLATION METHODS

AMS Acoustical Wall Panels can be mounted in a variety of ways:


Impaling Clips

Impaling Clips are the easiest way to mount our AMS Acoustical Wall Panels, especially if the panels do not need to be removable.

Impaling Clips are included with our panels and have a peel off adhesive tape on the back of each clip that will adhere to the surface that the panel is being mounted to. You can also screw the clip to a wall stud to secure if you wish.

Once you have secured the clips to the wall, apply a heavy duty construction adhesive (not included with panel orders) to the back of the panel and place panel on the wall in the desired location. Press the panel to the wall and apply pressure on areas where clips were mounted.

Impaling Clips are designed to hold the panel in place while the adhesive sets.



*Impaling clips are for wall mounting only. Do not use on ceilings.

Z-Clips


If you need to remove the wall panels at any time, we would recommend using Z-Clips. Z-clips are installed on the back of our panels with hard epoxy and shipped with loose clip to be mounted to the wall. Please specify panel orientation to wall when ordering as the clips on the backs of the panels cannot be removed.

Determine Z-Clip orientation on the wall by matching locations on panels.

Attach loose Z-Clips to wall with screws. (You can use washers between wall and Z-Clip)

Hang the Z-clips on the panels onto the Z-clips on the wall. (Picture hanging a flat panel TV on a wall)

* Make sure to measure correctly when hanging panels side by side



Rotofast Panel Anchors (WALLS & CEILINGS)

Rotofast™ Panel Anchors are an very easy method to install our acoustic wall & ceiling panels. Please make sure to use care when measuring orientation of panels so that they are straight. This method is to be used when easy removal is not required.

